E-1904996

# Addendum & Corrigendum No. 61 to General and Subsidiary Rule Book 2013 of S. E. C. Railway. (Corrected Copy)

In the General & Subsidiary Rule Book/SECR edition 2013 -

The following Modifications to USR 9.12 are amended by Railway Boards Joint Dricoter Traffic Trans-III No.2024/TT-IV/12/10 Dated 08.04.25

(1) The para 7 under SR 9.12/2(A) may be read as:

"After ensuring that the first train has arrived safely at the station ahead of the affected section, the loco Pilots/Motorman of all subsequent trains may be permitted to run at their sectional speed **duly proceeding with great caution from one kilometre before the Semi-Automatic/ Manual First Reception Stop Signal**, subject to other speed restriction in force. The speed over facing points, if any, being restricted to 15 KMPH."

- (2) Further, modified authority forms T/A 912 and T/D 912 are also annexed.
- A) Existing authority T/A 912 is revised as per Railway Board's letter no. 2024/TT-IV/12/10 Pt.1, dated 17.01.25 is enclosed in "Annex. I".
- B) **Existing authority T/D 912** is revised as per Railway Board's letter No.2024/TT-IV/12/10 Dated 08.04.25 is enclosed in "Annex. II".

This has the approval of competent authority M(O&BD).

Dy. Chief Operations Manager (Plg. & Safety)
For Principal Chief Operations Manager
SECR/Bilaspur

No. SEC/TRA/GSR/425/25

Dated: 17.04.25

#### **Circulations:**

- 1. Advisor (Safety)/ Rly. Bd., New Delhi.
- 2. Secy./SECR for kind information of GM.
- 3. PCOM, CFTM, CPTM, CTPM, CSO, PCSTE, PCEE, PCME, PCE.
- 4. DRM/BSP, R & NGP.
- 5. Sr. DSO, Sr. DSTE, Sr. DEN (Co-ord) /BSP, R & NGP.
- 6. Sr. DOM, Sr. DME, Sr. DEE (OP)/ BSP, R & NGP.
- 7. Principal- ZRTI/SINI, MDZRTI/BSP, ELTC/USL, STC/BIA & DTTC/DGG.

Dy. Chief Operations Manager (Plg. & Safety)

#### SEC RAILWAY

Form No. T/ A 912\*\*

Sr. No. \_

## AUTHORITY TO PASS AUTOMATIC/SEMI AUTOMATIC/MANUAL STOP SIGNAL/GATE STOP SIGNALS

(Loco Pilot / Train Manager / Station Master's Record)					
Station	Time:hours	• ,			
mins Date		- ,·			
To The Motorman/ Loco Pilot of Engine/ Train/ Unit No	UP/ DOWN.				
(c) Automatic Signalling has failed and you are, hereby authorized to pass all Automatic signals betweenstation andstation. In addition, you are also authorized to pass Semi-Automatic / Manual S t o p S i g n a l / gate stop signals on being hand signalled past such signals by a railway servant in uniform, the hand signals being displayed except as provided for in clause 'b'.					
(d) When running in wrong line (i) you must ascertain that points of outlying sidings, where provided, are correctly set and locked and/or the level crossing gates Nos. are closed and (ii) hand signals are displayed by the railway servant in uniform at the points/level crossing gates before passing them.  Here indicate distinguishing Number of all signals to be thus passed					
CAUTION ORDER		•			
Your Train is going to pass signal/s at ON, speed shall be restricted to 25 kmph when view is clear and 10 kmph when approaching or passing any portion of the line where the view ahead is not clear due to curve, obstruction, rain, fog subject to observance of other speed restriction in force.  The speed over facing points, if any, being restricted to 15 kmph.					
Signat	ure and Stamp of Statio	n Master			
I have understood the contents of this authority.					
Signature of Train Manager Date:Time Signature of Loco Pilot / Motorman Date:Time	_Hoursmin _Hoursmin				

\*\* T/A 912 shall always be issued along with one of these forms – T/B 602, T-511, T/F 602 or as prescribed in the SR of the Zonal Railway.

### SEC RAILWAY

Form No. T/ D 912

Serial	No	
251101	INO.	

<b>AUTHORITY FOR WORKING OF TRAINS</b>	
DURING PROLONGED SIGNAL FAILURE IN AUTOMATIC BLOCK S	YSTEM

(Loco Pilot / Train Manager / Station Master's Record)						
Station	, , , , , , , , , , , , , , , , , , , ,	Time:	hours_	mins		
Date			4			
То						
The Motorman / Loco Pilot of Engine / Train / Uni	: No		UP / [	DOWN.		
AUTHORIT	TO PROCEE	<b>D</b>				
1. All signals betweenstation an	d	station have	failed.			
2. Line clear has been received from	station_u	nder his Priva	ate No. (in	words)		
(in figures)			•			
3. You are authorized to work your Engine / Tra	in / Unit No	up to	the Semi-A	utomatic/		
Manual First Reception Stop Signal of		stat	ion and the	reafter be		
guided by the aspect of the Semi–Automa	tic / Manual	First Reception	n Stop Sign	al or the		
instructions from the Station Master of the _	station.					
AUTHORITY TO PASS S	GNALS IN 'O	N' POSITION				
You are also authorized to pass						
1. Departure signals and all intervening Automa	tic signals bet	ween		station		
andstation at "ON".						
2. Starter / Manual Stop Signal / Gate stop sign	als on being h	and signalled p	ast such sig	ınals by a		
railway servant in uniform.						
3. You shall cautiously pass level crossing gates	only after ens	uring that the	gates are clo	osed.		
4. Here indicated distinguishing numbers of al	i signals to be	e thus passed	• — • • • •	<del></del> -		
		•	* * * * * * * * * * * * * * * * * * * *			
CAUTION ORDER						
*Your train is the First train to pass over the UP /	•	lurina prolonae	nd failure of /	Automatic		
signaling fromstatio						
restricted to <u>25 kmph</u> when the view is						
impaired subject to other speed restric		10 KIIIDII WI	ieli view a	ineau is		
*Your train is NOT the First and is authorize						
station tostat						
other speed restrictions. Proceed with g	reat caution f	from km,	that is one	: Km		
before approaching Semi-Automatic/ Manu	al first Recep	tion Stop Sig	nal.			
The speed over facing points, if any, being restricted to 15kmph.						
*Strike out whichever is not applicable	) <b>.</b>					
			<del></del>			
	Si	ignature and S	tamp of Stat	ion Master		
I have understood the contents of this authority				2		
Signature of Train Manager	Date:	Time:	hours	mins		
Signature of Loco Pilot / Motorman	Date:	Time:	hours	mins		